


## TWO POWER SUPPLY MODES

- USB-C Cable: Connect to external power
- Batteries Mode: 5 AA 1.5V batteries (not included)


### NOTE FOR BATTERY USE:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Non-rechargeable batteries are not to be charged.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

## TO CHANGE BATTERIES



1. Use a cross-head screwdriver to open the battery cover.



2. Align the positive and negative poles and insert the batteries correctly. Replace battery cover with screwdriver.

## MAINTENANCE

- ① When the timing is at **00**, please keep the controllers in the middle position before inserting coins.
- ② If there is a controller malfunction, please restart and follow step ①.
- ③ If the machine constantly restarts, it may mean the batteries are getting low. Please replace with new batteries.
- ④ If the controllers don't work smoothly, please press down firmly to improve the function.
- ⑤ The chain may bind up accidentally. Please open the back door and straighten the claw chain while moving the claw controller up.
- ⑥ Regularly check the cord, plug, etc. If anything is damaged, please discontinue use.
- ⑦ This product contains electronic components. Do not put into water or use in a humid environment. To clean, wipe with dry towel.
- ⑧ Disconnect the machine from the power source before cleaning.



for other MindWare products visit [www.mindware.com](http://www.mindware.com)

© 2024 MindWare®  
2140 West County Road C  
Roseville, MN 55113  
Ph 800.274.6123

Adult supervision required.

3



## INSTRUCTIONS



**WARNING:**  
**CHOKING HAZARD—Small parts.**  
Not for children under 3 yrs.



## INTRODUCTION

Enjoy all the fun and excitement of an arcade with the Polar Prize Machine! As the music plays and the timer counts down, will you keep your cool and maneuver the claw to capture a prize?



## CONTENTS




Prize Machine, 10 Plastic Coins, USB-C Cable and 10 Plush Prizes

1

## SET UP



Load the prizes into the machine through the Prize Fill Window.



There are two ways to power your prize machine. You may either insert 5 AA 1.5V batteries (not included) following the directions on the back of these instructions or connect to an external power source using the USB-C cable provided. Change the source on the machine by moving the switch from batteries to USB-C on the back of the machine. This will start the music on the machine. To change the music tune, push the music button once.

## HOW TO PLAY



Insert a plastic coin or your own quarter to start the music and the 60 second timer.



Use the Movement Controller to move the claw forward, backward, left and right until the claw is positioned above the desired prize.



Push the Claw Controller downward to lower and open the claw. Push the Claw Controller upward to close and raise the claw. Once you have picked up a prize, move the claw above the Prize Chute and push the Claw Controller downward to open the the claw and release the prize.



Once your prize falls through the Prize Chute, an additional 20 seconds will be added so you can try to win another prize.

**SLEEP MODE:** After 3 minutes of no play, the machine will enter into sleep mode. Please press the music button to wake up.

2