

13783602 Log Cabin Playhouse Instruction Sheet

1. Color each piece how you see fit. Fold the tabs on piece A. Fold the tabs on piece B. Insert folded tabs of piece A into slots on piece B. Repeat for pieces C and D. Now attach A and B to C and D. See figure below.
2. Fold roof. Insert tabs at the top of pieces A, B, C and D into the slots on the roof.
3. Fold the tabs on the chimney piece so one tab is folded forward and one is folded back. Insert chimney piece into slot on top of the roof.

© 2017 OTC
MADE IN CHINA

