

13830791 VBS God's Galaxy Directional Sign Instructions

©2018 Oriental Trading Company, Inc.

OrientalTrading.com (800)-228-2269


PLEASE READ INSTRUCTIONS BEFORE YOU BEGIN

- Check that all materials are included in your kit.
- Make sure that your work area is large enough to assemble the item.
- Assembly time should be about 30 minutes for two people.

COMPONENTS INCLUDED

QTY. 1	A) SIGN POST
QTY. 4	B) POST SUPPORTS
QTY. 6	C) SHAPED SIGNS
QTY. 14	D) CLEAR PLASTIC PLUGS


B



C


SHAPES VARY

D



STEP 1:


Fold piece A into a box shape and secure the tabs.



STEP 2:


Fold the sides of B to create a triangular box shape as shown. Lift the flap on A and insert the tabs of B into the four slots on one side of A. To secure, insert the flap into the top slit on B.

Repeat with other B pieces.



STEP 3:


Use two D pieces to attach one C piece to A. Repeat with other C and D pieces until assembled.



Your Directional Sign is finished!

Have fun with your new directional sign! Use it as a display piece or as part of a scene.

WARNING!!!
THE DIRECTIONAL SIGN IS NOT CAPABLE OF SUSTAINING HEAVY WEIGHTS.



HELPFUL TIPS:

- When folding the pieces make sure the print is facing outward.
- Follow the diagram below to insert and close the tab openings.

