

13978267 Festival Venue Archway Instructions


COMPONENTS LIST

- QTY. 1 A) BOTTOM POST LEFT
- QTY. 1 B)TOP POST LEFT
- C) BOTTOM POST RIGHT
- D) TOP POST RIGHT
- E) BEAM
- QTY. 1 F) BANNER 1
- QTY. 1 G) BANNER 2
- QTY. 10 H) CLEAR PLASTIC PLUG












STEP 1: Fold pieces A through D along the score lines and form into square tubes. Secure the tabs.




BEFORE YOU BEGIN ASSEMBLY:


- Check that all materials are included in your kit.
- Please read through the instructions before you begin assembly.
- Make sure that your work area is spacious enough to assemble the item.
- Assembly time should be about 30 minutes for two people.

HELPFULTIPS:

- •When folding the pieces make sure the print is facing outward.
- Follow the diagram below to insert and close the tab openings.









STEP 2:

two posts.

STEP 3: Fold E along the score lines and form a square tube. Secure the tabs together.


Slide B into A to make one post, lining up the

tabs inward to secure the post together.

Repeat Step 2 by inserting


D into C to create a total of

seams and the square side tabs. Press the side




STEP 4:


Take E and with the slits facing downward, insert E into the square holes on the side of each post to create a frame. Once inserted press downward to secure the beam into place.



STEP 5:

Using the Plastic Plugs (H) attach the Banner pieces (F & G) to the top of the archway frame where shown.






Your arch is finished!

Have fun with your new arch!

Use it as a display piece or as part of a scene.



WARNING!!! THIS STAND-UP IS NOT CAPABLE OF SUSTAINING HEAVY WEIGHTS.



