

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

5124525 Twitching Ghoul

This item, when assembled by the following instructions, should take 15 minutes to assemble. Please follow the step by step guide and enjoy your Twitching Ghoul!

CARE AND STORAGE INSTRUCTIONS

For best performance, operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by the manufacturer.
2. Please assemble the item according to the instructions. Connect all wires according to their matching color.
3. Children should be supervised by adults. The item should not be grabbed, as it becomes a tipping hazard. Keep away from the adapter, as it heats up during operation.

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

PARTS LIST

- A. Base
- B1. Right Foot
- B2. Left Foot
- C. Lower Support Poles x 2
- D. Upper Support Poles x 2
- E. Foam Tubes x 2
- F. Pants
- G. Motor Support Frame
- H. Hip Frame
- I. Torso Frame
- J. Shirt
- K. Sensor
- L. Left Arm
- M. Right Arm
- N. Head
- O. Belt
- P. Gauze x 2
- Q. Step Pad

Adapter
Input: 100 - 240VAC 50/60Hz
Output: 5.9V 1.5A

BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921.

1

2

STEP1

NOTE: The longer end of the (A) Base should be facing forward.
Place the (B1) Right Foot and (B2) Left Foot over the exposed poles on the (A) Base as shown. Then secure the (C) Lower Support Poles to the exposed poles on the (A) Base using the quick connect push buttons and pre-drilled holes.

1


2

STEP2

Attach the (D) Upper Support Poles to the (C) Lower Support Poles by using the quick connect push buttons and pre-drilled holes. Slide the (E) Foam Tubes over the assembled support poles as shown.




STEP3
Slide the (F) Pants over the (E) Foam Tubes as shown. Assemble the (G) Motor Support Frame onto the (D) Upper Support Poles by using the quick connect push buttons and pre-drilled holes.



OPTIONAL: If you choose to use the Step Here Try-Me Activation Pad, plug the connector into the input receiving jack marked "TRY ME" on the Function Control Box and set the Step Pad in front of the character when ready to display.

STEP4
Now, plug the Power Adapter into the input receiving jack marked "DC 5.9V" on the Function Control Box. Do not plug the adapter into power outlet until item assembly is completed. Slide the (H) Hip Frame into the housings provided on the (G) Motor Support Frame as shown. Attach the (I) Torso Frame to the (G) Motor Support Frame using the quick connect push button and pre-drilled hole available as shown.



STEP5
Slide the (J) Shirt over the (I) Torso Frame so that the opening of the (J) Shirt is in the back. Secure the (K) Sensor to the inside of the (J) Shirt using the available hook & loop closure. The sensor should be aiming out of the hole.



STEP6
Slide the (L) Left Arm up the left sleeve of the (J) Shirt. Slide the forked hook of the (L) Left Arm into the forked hook housing available on the (I) Torso Frame as shown. Then slide the (M) Right Arm up the right sleeve of the (J) Shirt. Slide the forked hook of the (M) Right Arm into the forked hook housing available on the (I) Torso Frame as shown.



STEP7

Attach the (N) Head to the (I) Torso frame using the quick connect push button and pre-drilled hole. Connect the (K) Sensor Cable to the corresponding cable from the function control box. Connect the motor cable to the corresponding cable from the function control box. Connect the black cable from the (I) Head to the corresponding cable from the function control box.



STEP8

Seal the (J) Shirt at the back using the hook & loop closures. Secure the (O) Belt around the waist of the assembly. Then drape the (P) Gauze over both arms. Style the Twitching Ghoul for best results. The Twitching Ghoul is now fully assembled.

OPERATION INSTRUCTIONS:

1. Plug the AC power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (I) Torso Frame, as desired.

2. Settings:

Sensor: This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.

○ / OFF / Try Me: This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad. The item will operate for one audio cycle with each Try Me activation. Refer to Assembly Instructions Step4 for further details.

I / ON : This switch mode will continuously operate the lights, sound, and animation of the item.

 : Raise or lower the volume using the volume control turn dial, turn and click all the way down to turn the volume off.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

