

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

5124529 See Saw Clowns



This item, when assembled by the following instructions, should take 15 minutes to assemble. Please follow the step by step guide and enjoy your See Saw Clowns!

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by the manufacturer.
2. Please assemble the item according to the instructions. Connect all wires according to their matching color.
3. Children should be supervised by adults. The item should not be grabbed, as it becomes a tipping hazard. Keep away from the adapter, as it heats up during operation.

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

PARTS LIST

- A. Base
- B. Teeter Frame
- C. Support Poles x 2
- D. Girl Clown
- E. Boy Clown
- F. Sensor
- G. Sign
- H. Fabric Cover
- I. Step Pad

AC Adapter *
Input: 100 - 240VAC 50/60Hz
Output: 5.9V 1.5A

BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921.

STEP HERE

OPTIONAL: If you choose to use the (J) Step Pad, plug the connector into the input receiving jack marked "TRY ME" on the Function Control Box.

STEP 1

Secure the (B) Teeter Frame to the (A) Base by aligning the quick-connect push button into the pre-drilled hole as shown in Figure 1.

Now, plug the Adapter into the input receiving jack marked "DC 5.9V" on the Function Control Box.

Note: Do not plug the Adapter into power outlet until item assembly is completed.

Assemble the (C) Support Poles to the (B) Teeter Frame as shown in Figure 2 and secure by aligning the quick-connect push buttons into the pre-drilled holes.

1

2


3

4

STEP 2

Attach the (D) Girl Clown into the slots located at the end of the (C) Support Poles as shown in Figure 1. Secure the (D) Girl Clown's hands with the hook & loop closures as shown in Figure 2.

Attach the (E) Boy Clown into the slots located at the other end of the (C) Support Poles as shown in Figure 3. Secure the (E) Boy Clown's hands with the hook & loop closures as shown in Figure 4.



STEP 3
 Slide the cables to the (D) Girl Clown and the (E) Boy Clown through the metal rings under the (C) Support Poles, connect to the coordinated cables on the (B) Teeter Frame as shown in Figure 1 & 2.
 Connect the cable from the (F) Sensor to the coordinated cable on the (B) Teeter Frame as shown in Figure 2.
 Wrap the (G) Sign around the (B) Teeter Frame, make sure the bottom of each panels slide into the slots located on the (A) Base as shown in Figure 3.1, then Secure the (G) Sign with the hook & loop closures as shown in Figure 3.2.




STEP 4
 Attach the (F) Sensor to the (G) Sign using the hook & loop closures as shown in Figure 1.
 Note: Please make sure the (F) Sensor is visible from the outside.
 Secure the (H) Fabric Cover to the inside of the (G) Sign with the hook & loop closures as shown in Figure 2.

OPERATION INSTRUCTIONS:

1. Plug the AC power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (B) Teeter Frame, as desired.
2. Settings:
 On: This setting allows the item to run continuously.
 Off/Try-Me: This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad. The item will operate for one audio cycle with each Try-Me activation. Refer to Assembly Instructions Step 1 for further details.
 Sensor: This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.

: Raise or lower the volume using the volume control turn dial, turn and click all the way down to turn the volume off.



CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.