EASY ASSEMBLY AND OPERATION INSTRUCTIONS

MR-124858 Hooded Phantom



Please follow the step by step guide and enjoy your **Hooded Phantom!**

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

WARNING


This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

- 1. Please use the adapter supplied by manufacturer.
- 2. Please assemble item according to instructions. Connect all wires according to matching color.
- 3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep all away from the adapter, as it heats up during operation.

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.



BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, PLEASE CONTACT CUSTOMER SERVICE AT SUPPORT@MORRISCOSTUMES.COM, OR BY PHONE 704-332-3304. IN YOUR EMAIL INQUIRY, PLEASE INCLUDE: YOUR ORDER NUMBER, WHO YOU BOUGHT IT FROM, AND WHAT SPECIFICALLY IS WRONG. THANK YOU.



STEP 1

NOTE: Throughout the instructions, left and right are relative to the character.

Attach the (B) Lower Support Pole to the (A) Base and secure by aligning the quick-connect push button into the pre-drilled holes as shown in Figure 1.

Slide the supports located on the (A) Base into the slots located on the (B) Lower Support Pole as shown in Figure 2.

Attach the (C) Upper Support Pole to the (B) Lower Support Pole and secure by aligning the quick-connect push button into the pre-drilled holes as shown in Figure 3.



STEP 2

NOTE: The speaker on the Function Control Box located on the (D) Torso Frame should be facing

Assemble the (D) Torso Frame onto the (C) Upper Support Pole and secure by aligning the quick-connect push buttons into the pre-drilled holes as shown in Figure 1. Attach the (E) Right Arm to the (D) Torso Frame and slide the forked hook into the right "shoulder"

slot housing on the (D) Torso Frame as shown in Figure 2.

Attach the (F) Left Arm to the (D) Torso Frame and Slide the forked hook into the left "shoulder" slot housing on the (D) Torso Frame as shown in Figure 3.



STEP 3

Set the (G) Head onto the (D) Torso Frame by sliding the forked-hook into the "neck" slot housing on the (D) Torso Frame as shown in Figure 1.

Connect the cable from the (G) Head to the corresponding cables from the Function Control Box located on the (D) Torso Frame and connect the cables from the (E) Right Arm & (F) Left Arm to the corresponding cables from the Function Control Box located on the (D) Torso Frame as shown in Figure 2.

Attach the (H) Costume to the (D) Torso Frame & the (G) Head as shown in Figure 3 and secure with the hook & loop closures, as shown in Figure 3.1/3.2/3.3.



STEP 5

Attach the (I) Curtain to the (D) Torso Frame and secure with the hook & loop closures as shown in Figure 1 & 2.

Your Hooded Phantom is now fully assembled. Plug in and turn on to let the fun begin!

OPERATION INSTRUCTIONS:

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (D) Torso Frame, as desired.

2. Settings

Sensor: This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is



STEP 4

Attach the (H) Costume to the (E) Right Arm and secure with the hook & loop closures as shown in Figure 1.

Make sure the sewing line towards the front of the (E) Right Arm as shown in Figure 2. Attach the (H) Costume to the (F) Left Arm and secure with the hook & loop closures, then secure the sensor located on the (F) Left Arm to the (H) Costume with the hook & loop closures as shown in

Make sure the sewing line towards the front of the (F) Left Arm as shown in Figure 4.

activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.

○/OFF/Try Me: This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad. The item will operate for one audio cycle with each Try Me activation. Refer to Assembly Instructions Step2 for further details.

/ ON : This switch mode will continuously operate the lights, sound, and animation of the item.



- : Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

