

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

MR-124651 & MR-124653 Tug-Of-War Clowns

Please follow the step by step guide and enjoy your Tug-Of-War Clowns !

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by manufacturer.


2. Please assemble item according to instructions. Connect all wires according to matching color.

3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep all away from the adapter, as it heats up during operation.


Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

PARTS LIST

- A. Right Base
 - B. Left Base
 - C. Base Poles x 2
 - D. Right Clown Shoes
 - E. Left Clown Shoes
 - F. Right Leg Poles x 2
 - G. Left Leg Poles x 2
 - H. Foam Tubes x 4
 - I. Right Clown Pants
 - J. Left Clown Pants
 - K. Right Clown Torso Frame
 - L. Left Clown Torso Frame
 - M. Right Clown Support Pole
 - N. Right Shoulder Support
 - O. Left Shoulder Support
 - P. Right Clown Head
 - Q. Left Clown Head
 - R. Right Clown Costume
 - S. Left Clown Costume
 - T. Child
 - U. Collar
 - V. Left Clown Hat
 - W. Step Pad
 - X. Adapter (Included)
- Input: 100 - 240VAC 50/60Hz
Output: 5.9V 2A



BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, PLEASE CONTACT CUSTOMER SERVICE AT SUPPORT@MORRIS COSTUMES.COM, OR BY PHONE 704-332-3304. IN YOUR EMAIL INQUIRY, PLEASE INCLUDE: YOUR ORDER NUMBER, WHO YOU BOUGHT IT FROM, AND WHAT SPECIFICALLY IS WRONG. THANK YOU.




STEP 1

Attach the (C) Base Poles to the (A) Right Base & the (B) Left Base and secure by aligning the quick-connect push buttons into the pre-drilled holes as shown in Figure 1.

Lower the (D) Right Clown Shoes over the (A) Right Base and the (E) Left Clown Shoes over the (B) Left Base as shown in Figure 2.


Attach the (F) Right Leg Poles to the (A) Right Base & the (B) Left Base and secure by aligning the quick connect push buttons into the pre-drilled holes as shown in Figure 3.



STEP 2

Attach the (G) Left Leg Poles to the (A) Right Base & the (B) Left Base and secure by aligning the quick connect push buttons into the pre-drilled holes as shown in Figure 1.

Slide the (H) Foam Tubes over the (F) Right Leg Poles & the (G) Left Leg Poles as shown in Figure 2.




STEP 3

Lower the (I) Right Clown Pants & the (J) Left Clown Pants over the assembled Knee poles as shown in Figure 1.

Assemble the (K) Right Clown Torso Frame & the (L) Left Clown Torso Frame onto the (F) Right Leg Poles & the (G) Left Leg Poles and secure by aligning the quick-connect push buttons into the pre-drilled holes as shown in Figure 2.

Now, plug the Adapter into the input receiving jack marked "DC 5.9V" on the Function Control Box and route the Power Adapter down and out the bottom of the item.



STEP 4


Put the (M) Right Clown Support Pole through the (J) Left Clown Pants as shown in Figure 1.

Set the hook of the (M) Right Clown Support Pole on the ring located on the (L) Left Clown Torso Frame as shown in Figure 2.

Set the end of the (M) Right Clown Support Pole on the ring located on the (B) Left Base as shown in Figure 3.

Attach the (N) Right Shoulder Support & the (O) Left Shoulder Support to the top of the (J) & (K) Torso Frame using the quick connect push buttons and pre-drilled holes as shown in Figure 4.

Set the (P) Right Clown Head & the (Q) Left Clown Head onto the (N) & (O) Shoulder Supports by sliding the forked hook into the "neck" slot housing on the (N) & (O) Shoulder Supports as shown in Figure 5.




STEP 5

Connect the cable from the (Q) Left Clown Head to the color-coordinated cables on the (L) Left Clown Torso Frame as shown in Figure 1.

Attach the (R) Right Clown Costume to the (N) Right Shoulder Support and the (S) Left Clown Costume to the (O) Left Shoulder Support, then put the sleeves through the arms located on the (N) & (O) Shoulder Supports as shown in Figure 2.

Pull out the pins located on the (N) Right Shoulder Support as shown in Figure 3 & 4.




STEP 6

Pull out the pins located on the (O) Left Shoulder Support as shown in Figure 1 & 2.


Attach the forked hook at the end of the (N) Right Shoulder Supports to the pegs which are located on the (T) Child as shown in Figure 3 & 5.

Insert the pins into the hole of the available pegs on the (T) Child to fasten the (N) Right Shoulder Supports in place as shown in Figure 4 & 6.



STEP 7

Attach the forked hook at the end of the (O) Left Shoulder Supports to the pegs which is located on the (T) Child as shown in Figure 1 & 3.
Insert the pins into the hole of the available pegs on the (T) Child to fasten the (O) Left Shoulder Supports in place as shown in Figure 2 & 4.
Connect the cables from the (P) Right Clown Head to the color-coordinated cables on the (T) Child as shown in Figure 5.
Connect the cables and sensor cable from the (L) Left Clown Torso Frame to the color-coordinated cables on the (T) Child as shown in Figure 6.



STEP 8

Attach the (R) Right Clown Costume to the (P) Right Clown Head using the hook & loop closures as shown in Figure 1.
Secure the back of the (R) Right Clown Costume with the hook & loop closures as shown in Figure 2.
Attach the (S) Left Clown Costume to the (Q) Left Clown Head using the hook & loop closures as shown in Figure 3.
Secure the back of the (S) Left Clown Costume with the hook & loop closures as shown in Figure 4.
Secure the back of the (U) Collar with the hook & loop closures as shown in Figure 5.
Secure the braces of the (I) Right Clown Pants with the hook & loop closures as shown in Figure 6.
Place the (V) Hat onto the (Q) Left Clown Head and secure with the hook & loop closures as shown in Figure 7.
Your Tug-Of-War Clowns are now fully assembled. Plug in and turn on to let the fun begin!

OPERATION INSTRUCTIONS:

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the Left Clown Torso Frame, as desired.

2. Settings:

Sensor: This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.

O / OFF / Try Me: This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for one audio cycle with each Try Me activation. Refer to Assembly Instructions Step3 for further details.

I / ON : This switch mode will continuously operate the lights, sound, and animation of the item.

Volume Control: + : Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

